

Instructions

Tripod HM9 Hvidt & Mølgaard 2023




Please read these instructions carefully and retain them for future reference to ensure the product is used correctly. For your own safety, please study each step of this instruction manual before installation. &Tradition is not responsible for any faults or damage caused by not following these instructions correctly. Do not modify this product in any way. If you have any questions or comments, please do not hesitate to contact us by mail on: info@andtradition.com

&Tradition®

Tripod HM9

Hvidt & Mølgaard

2023



Safety precautions

- Dispose of plastic bag from packaging immediately and keep out of reach of children.
- The lamp is only intended for interior use.
- Do not place the cable within reach of small children or anywhere there is a risk of it becoming a trip hazard.
- If the external cable or cord of the lamp is damaged, it must be replaced by the manufacturer or a similarly qualified person to avoid any potential hazards.
- Consult a professionally qualified electrician if in any doubt.
- Keep the product well out of reach of children.
- Always ensure product is disconnected from power source before attempting any part of the installation process.

Contents

- A Lampshade

Tools needed

- Bulb type E14

Cleaning instructions

- Wipe surface of the shade with a soft dry cloth.
- Do not use any abrasive cleaning tools such as steel wool, scouring sponges or stiff brushes.
- Never use strong cleaning agents such as white spirit, turpentine, household glass cleaner or cellulose thinners.

12/23


For indoor use only
E14 Maximum 25W
Bulb not included



Please follow steps 1 to 4 to assemble the product.


Step 1 / 3

The lamp is delivered fully assembled. Install the light bulb in the socket.



Step 2 / 3

Once the light bulb is installed, rotate the shade by using the flexible joint to achieve the desired angle. Caution: we recommend setting the angle before turning on the lamp as the shade will become hot to the touch once the lamp is in use for longer periods of time.



Step 3 / 3

Insert the plug into a wall socket and use the switch located on the lamp's cord to turn on and off.

